

Guide and Information to the use of Mould Prep

1. Carefully remove the body molding from the vehicle.
2. Once molding is removed place it into soaker-tray which holds approximately 2 gallons of the mould prep fluid.
3. The type of double-sided tape determines the length of time the molding should soak fully immersed in tray.
4. Neoprene tapes approximately 8 to 10 hours. Usually Black
5. VHB acrylic foam tape 8 to 10 hours. (Very High Bonding) Gray or White. 24 hours or longer.
6. Emblems can also be placed in fluid without fear of damage.
7. After the recommended time the molding is removed from the soaker-tray, the double-sided tape will peel away.
8. When all tape is removed thoroughly wipe off all excess fluid with clean rag and re-tape with double-sided tape.
9. The molding is now ready to be replaced.

DANGER: Contains petroleum distillates. Combustible product use foam or powder extinguisher. Vapor harmful. Use only in well ventilated area. Do not use near heat, sparks, or flame. Avoid prolonged breathing of vapor. Avoid contact with eyes and skin.

FIRST AID: SKIN/EYES: Flush thoroughly with water for 15 minutes, seek prompt medical attention.

INGESTION: If swallowed do not induce vomiting. Give one or two glasses of water, call medical personnel immediately.

INHALATION: Remove victim to fresh air/restore breathing, call medical personnel immediately.

STORAGE: Store in cool well ventilated area away from heat or ignition source. container should always be closed in proper labeled container. **KEEP OUT OF REACH OF CHILDREN**

⚠ **WARNING:** Cancer and Reproductive Harm. www.P65Warnings.ca.gov.

1. Con cuidado quite la moldura de vehículo.
2. Cuando a quitado la moldura póngala a remojar en una bandeja que mantenga aproximadamente 2 galones de liquido Mould Prep.
3. Lo largo de la cinta de doble pegamento determina el tiempo que se remoja la moldura en la bandeja.
4. Cintas de neopreno son aproximadamente de 8 a 10 horas. (Usualmente son negras.)
5. Cintas de esponja acrílica muy pegajosas deben remojar de 8 a 10 horas o mas de 24 horas. (Usualmente son grises o blancas.)
6. Los emblemas se pueden poner en liquido sin peligro de dañarse.
7. Después del tiempo recomendado saque la moldura de la bandeja, y se despega la cinta de doble pegamento.
8. Cuando la cinta se ha quitado limpie el exceso con una toalla si es necesario. Coloque la nueva cinta de doble pegamento.
9. Ahora la moldura esta lista para colocarse.

PELIGRO: Contiene deterpene pinene combinado de aceites esenciales y petróleo. Producto de combustible. Utilizar en áreas bien ventiladas. No usare cerca de fuego. Evite respirar el vapor por largo periodo de tiempo. Evite contacto con los ojos y piel.

EN CASO DE EMERGENCIA:

CONTACTO CON LOS OJOS : Lávese con agua por 15 minutos y busque atención medica.

CONTACTO A LA PIEL : Lávese con jabón y agua.

INGERIR : *NO PROVOQUE VOMITO* y vea el doctor inmediatamente.

ALMACENAMIENTO: Mantenerse en área bien ventilada y fresca fuera del calor y

peligro de incendio. El producto debe mantenerse siempre en el envase original. **EN**

CASO DE FUEGO: Utilizar un extinguidor de polvo o de espuma. **Producto Flamable.**

MANTENGASE FUERA DEL ALCANCE DE LOS NIÑOS.

⚠ **ADVERTENCIA:** Cáncer y daños al sistema reproductivo- www.P65Warnings.ca.gov.

